

BLAUPUNKT
User manual



Enjoy it.

Wireless earphones

Safety Precautions

Read these safety instructions before using your device and store them for possible future reference.

- The device is not intended for use by persons (including children) with reduced physical, sensory or mental capacity. Persons who have not read the manual, unless they have received explanations by a person responsible for their safety and supervision should not use this unit.
- Children should be monitored to ensure that they do not play with the device.
- The device should always be readily accessible.
- The device should not be exposed to dripping or splashing water.
- No objects filled with liquids such as vases shall be placed on the device.
- Always leave a minimum distance of 10 cm around the unit to ensure sufficient ventilation.
- Open flame sources, such as candles, should not be placed on top of the device.
- The device is intended for use only in a temperate climate.
- At full volume, prolonged listening to the portable audio device may damage the user's hearing and cause hearing troubles (temporary or permanent deafness, hearing drone, tinnitus, hyperacusis).
- So, we recommend not to listen to the portable audio device at high audio volume and no more than one hour per day at medium audio volume.
- CAUTION: Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent.
- The battery should not be exposed to excessive heat such as sunshine, fire or similar.
- Different types of batteries, new and used batteries should not be mixed.
- The battery must be installed according to the polarity.
- If the battery is worn, it must be removed from the product.
- The battery must be disposed of safely. Always use the collection bins provided (check with your dealer) to protect the environment.
- The battery can't be replaced by the user, but only by the maker of this product, the after sales department or a qualified person.

SWITCH OFF IN RESTRICTED AREAS

Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger, for example on board an aircraft, near medical equipment, fuel, chemicals or blasting sites.

ROAD SAFETY COMES FIRST

Check the current laws and regulations regarding the use of this device in the areas where you drive.

- Do not handle the device when driving.
- Concentrate fully on the driving
- Radio signals could affect some of the car's electronic systems such as the audio stereo and alarm systems.

INTERFERENCE

All wireless devices are susceptible to interference which may affect their performance. All our device conforms to international standards and regulations, and if need be national ones, with a view to limiting user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices.

AUTHORISED PERSONNEL

Only qualified people are authorized to install or repair this product.

ACCESSORIES

Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products.

CHILDREN

Keep your device in a safe place, out of the reach of young children. The device contains small parts that may present a choking hazard.

Specifications

Rated voltage: DC 5V \equiv 1A

Max consumption: 0.228W

Li-Po battery: 400mAh / 2x40mAh

Sound power: 2 x 5mW

Max RF power : 3.98mW

Radio frequency : 2402-2480MHz

Frequency range: 20Hz-20KHz

Bluetooth compatible version: 5.0

Distance Bluetooth stays connected: 10m

Music playing time: Around 5-6 hours

Charging time: 1-2 hours

Size: 52 x 48 x 26mm

Weight: 46g

Product presentation

Definition	L	R	Voice
One Tap ①	(Playing music) pause/play	(Playing music) pause/play	N
One Tap ②	(Phone coming) answer	(Phone coming) answer	N
One Tap ③	(On calling) hang up	(On calling) hang up	N
Double Tap	Volume+	Volume-	"du" &"max volume"
Triple Tap	Voice assistant Siri	Voice assistant Siri	N
Touch & Hold 2-3sec ①	(Playing music) Next song	(Playing music) Previous song	N
Touch & Hold 2-3sec ②	(Incoming call) reject	(Incoming call) reject	N
Touch & Hold 7-8sec	Power on/off	Power on/off	Power on/Power off

Pairing

- 1- Please ensure that earbuds and charging case are charged. If not please charge them.
- 2- Open charge case and take out both earbuds. You will hear a voice "**DONG DONG**", your earbuds are connected each other and ready to be paired, LED light of right earbud will be flashing quickly.
- 3- Search on your mobile device Bluetooth function and connect it to the device name "**BLP4899**". If successful, you will hear "**connected**" and LED light will turn off.

Charging

- 1- Earbuds

Put them on the charging case to start charging. The LED lights up red on both headphones and green on the charging box until full charge, after the LED will turn off. When the headphones load, the number on the charging box flashes for each of them.

- 2- Charging case

Charge you charging case with USB/Type C cable provided. Green number will flash until showed "100".

About the single and both earbuds use

When you connected both earbuds with device. You can put anyone piece into charge case. It will not affect another one use. And when you take the earbud out of case, it still can be dual paired status with another one.

About auto power-off

When you take the earbuds out of case but not connected with device within 3 minutes, the earbuds will power off automatically.

About low battery

When earbuds in low battery status, it will voice you "low battery, please charge». At this time, please put the earbuds into case for charge.

Whether pairing successes

If pairing failed. The 2 earbuds will not be connected at same time. You can put them into case and take them out again and waiting 5s try.

Confirm whether both earbuds turn on

If only one earbud can hear sounds, please check whether both earbuds have power or not. If not please charge first. Turn on have 2 way:1. Take the earbuds out from case;2. Long tap about 4-6s.

Confirm the charge case have power or not

When the charge case under low battery or no power status, it can't recognize earbuds. Whatever turn on/off. Also, the case green LED light will show"00" or nothing.

If earbuds put in case cannot charging

Please check the earbuds bottom point whether covered other stuff. It will affect the earbuds charging function. Also need keep earbuds and charging case clear. If dirty, you can use alcohol to wipe.

Declaration of conformity UE

Dag Technologies®, hereby declares that this equipment conforms to the essential requirements and other relevant provisions of Directive 2014/53/UE. The declaration of Conformity can be viewed at the following address:

http://www.mms-support.net/OTA/ECD_DAG_BLP4899-004.pdf

The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain, and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected.



To avoid possible hearing damage, do not listen at high audio volume for long periods of time.

Imported by Dag Technologie®
79/81 Ancienne route Nationale 7
69570 Dardilly
FRANCE
www.blaupunkt.com

Enjoy it.

Dag Technologie®
79/81 Ancienne Route Nationale 7
69570 Dardilly – France