

18V CHAINSAW CS2010









The CS2010 cordless chainsaw is an ideal tool for work in the garden or on the allotment. It is lightweight, handy and easy to use. It doesn't need a cable or fuel, just charge the 18V battery and you're ready to go. You can cut wood, branches or bushes with precision and speed.



DISTRIBUTOR:

2N-Everpol Sp. z o.o. - BLAUPUNKT COMPETENCE CENTER, 02-801 WARSZAWA, 403A PUŁAWSKA St., POLAND Tel: +48 22 688 08 00, www.everpol.pl, info@everpol.pl





FEATURES AND SPECIFICATIONS:

- Voltage: 18 V
- Total chain guide length: 156 mm
- Chain speed: 4.7 m/s
- Speed: 3200 min-1
- Maximum depth of cut: 110 mm
- Accessories: 1 x belt clip, 1 x screwdriver (for chain tension adjustment)
- Battery type: 18 V Li-Ion, 4.0 Ah recommended (not included)

INCLUDES:

- 1 x belt clip
- 1 x screwdriver (for adjusting chain tension)
- User Manual
- Warranty card

DIMENSIONS AND WEIGHT OF THE DEVICE:

- Dimensions: 41 x 11.5 x 16 cm
- Weight: 1.5 kg

LOGISTICAL DATA:

Unit packaging

- Dimensions: 45 x 15.3 x 17.8 cm
- Weight: 1.53 kg.

Bulk packaging

- Dimensions: 47 x 33 x 20 cm
- Weight: 5.22 kg
- Number of pcs: 2

EAN code: 5901750506673 CN code: 8467 22 10

